COPY






Place original(s) face up in Auto Document Feeder or face down on the Platen Glass.

- 1. Select the COPY function from the home page on the touch screen.
- 2. Using the number key pad, enter the desired quantity.
- 3. Press the Start button. If copying from the glass press # after placing last original

Additional Copy Features



- 1. Status messages/Error messages
- 2. Paper Trays -- [Auto Paper Select] automatically selects paper based on original size.
- 3. Duplex options -- 1-sided originals to 2-sided copy, 2-sided original to 2-sided copy, 2-sided original to 1-sided copies 4. Staple options -- Dash indicates where the set will be stapled.
- Sort (collated) or Stack (non-collated) multiple sets
- Original Type settings
 - [Auto Color Select] -- Used for mixed originals; deciphers between B&W and color and copies accordingly.
 - [Full Color] -- Copies color originals in color by overlying cyan, yellow, magenta, and black.
 - [Black & White] -- Copies color or Black & White originals in Black & White. C.
 - [Text] -- Originals contain only text. Text is the default. D.
 - [Photo] -- Delicate tones and gray scale is reproduced from photos or pictures. E.
 - [Text/Photo] -- Originals contain a combination of text and photos or pictures.

Scan to Email






Place original(s) face up in Auto Document Feeder or face down on the Platen Glass.

- 1. Select the **SCANNER** function from the home page on the touch screen.
- 2. Select the preprogrammed destination or Manual Entry to enter a email address.
- 3. Press the Start button. If scanning from the glass press # after placing last original

Additional Scan Features



- 1. [Scan Settings] changes the default Text selection. Choose from available B/W or Color settings.
- 2. [Original Feed Type] allows for scanning 2-sided originals and Batch scanning.
- 3. [File Name/Type] is used to assign a file name and the change the file type. When choosing [Single Page TIFF/JPEG] or [Single Page PDF], each page of the scan will be received as a separate attachment. When choosing [Multi-Page TIFF] or [Multi-Page PDF], all scanned documents will be received as one file.
- 4. [Text] is used to add a message to the body of the e-mail.
- 5. [Subject] is used to attach a subject to the e-mail.
- 6. Select destinations from pre-programmed one-touch keys, or select [Manual Entry] to enter an e-mail address not programmed. Multiple destinations may be selected.
- 7. Some MFDs may require each scan to attach a sender's name. If so, select [Sender Name] and choose from the available one-touch destinations shown.